


HA02 Side Pole Crook

revision 6/2/14 • kl\_ha02\_spec.pdf





Type: Job:

Page: 2 of 3

# **Standard Features**

ERA® Arm	Arm/Fixture	Mounting Configuration						
HA02		Plan View:	•-	•-•	•.•	•	€	
		Cat. No.:	1 <b>A</b>	2B	3Y	4C	1W	
	Large	EPA:						
	HA02L - RA25		1.9	3.8	5.1	5.9	n/a	
	HA02L - AE21/BE21		1.8	3.6	4.8	5.5	n/a	
	HA02L - LET26		2.0	4.0	5.2	6.0	n/a	
	Small							
	HA02S - RA17		1.3	2.6	3.5	3.9	n/a	
	HA02S - AE17/BE17		1.2	2.4	3.2	3.6	n/a	
	HA02S - LET19		1.5	3.0	4.0	4.5	n/a	



#### Type: Job:

### Page: 3 of 3

# **Optional Features**

### Wall Mounting

Cat. No. **1W** Select from Mounting on page **2**. A cast mounting plate of aluminum is mounted to the wall with bolts (by others). Fixture and arm are mounted to a cast aluminum cover plate before attaching to the wall mounting plate. The fixture-arm-cover plate assembly is hooked to the wall mounting plate, and secured with stainless steel screws provided. After mounting to the wall, field splices are made at the opening in the cover plate, then covered by a cast aluminum plate that blends with the cover plate design. Complete fixture-arm-cover plate assembly can therefore be mounted before field splices are made. Cover plate is finished to match arm and fixture powder coat color.

**CAUTION:** Structural integrity of mounting plate attachment to wall is by others.

