

| CATALOG # | | TYPE |
|-----------|---------|---------|
| JOB NAME | WATTAGE | VOLTAGE |

SmartLED™ MRI Lighting System

MRP-22275-2500L

Ultra-slim 35W LED 2x2 White Panel

Up to 60,000 Hour Life • LM-80 Qualified • LM-79 Certified Photometry

For MRI Installations, use of both SmartLED™ Driver Modules and Filters is REQUIRED or Kirlin warranty is null and void.

Specifications

Luminaire Features

- Driverless, 35 watt, low voltage, Class II, DC powered.
- Color temperature: 3500°K standard. Optional: -41K.
- Must use in conjunction with SmartLED™ MRI Lighting System.
- Ultra-thin extruded aluminum design. White finish; for custom color see Option -94.
- · Completely non-ferro magnetic.

Thermal Management

 Housing / heat sink provides maximum heat dissipation for side-fire LED technology.

SmartLED™ MRI Lighting System Required (Order Separately)

- SmartLED™ MRI Cabinet.
- SmartLED™ MRI Driver Modules.
- SmartLED™ Filters.

SmartLED™ Emergency Backup System

- EMI-21220 for emergency power.
- · See specification sheet; order separately.

Trim / Lens

- Regressed trim provides a unique, architectural "skylight" effect when installed in grid ceiling.
- Extruded acrylic, wave guide lens provides unparalleled uniformity and even illumination of the image.

nstallation

- Requires minimum 18 AWG twisted pair shielded wire from SmartLED™ MRI Lighting System to fixtures.
- Drops into 2' x 2' ceiling grid.

UL, C-UL (Canada) Listings

· Wet, damp, dry locations, covered ceilings.

FCC Compliance

FCC Part 15 certified for EMI/RFI emissions.

FIVE YEAR Limited Warranty

Complete standard fixture.

| MUST SPECIFY | OPTIONAL | |
|-----------------|---------------------|------------------------|
| Product Number | Options | |
| MRP-22275-2500L | | Ordering Example: |
| | See "Options" below | MRP-22275-2500L-41K-BG |

Options

Color Temperature (CCT)

-41K Color temperature 4100°K instead.

Lens and Trim

- -94 Custom color/finish. Specify. Consult factory.
- -BGT Kirlin BioGard™ anti-microbial finish trim (white only).

Other

-99 Special modification. Consult factory.



Kirlin reserves the right to make changes without further notice to any products herein to improve reliability, function, or design. Kirlin does not assume any liability arising out of the application or use of any product described herein; neither does it convey any license under its patent rights, nor the rights of others.


red.




FCC Part 15 Certifie



Dimensions



Luminaire is available in nominal 2' x 2' size only.



Detailed Photometry - Installed Fixture

Photometric testing done in accordance with IESNA LM-79


-2500L

Lumens: SC: LPW: 3049 1.2 102 99.9% Efficiency:



| CANDLEPOWER DISTRIBUTION | | | | | | | | |
|--------------------------|------|------|------|------|-------|-------|-------|--|
| | 0.0 | 30.0 | 60.0 | 90.0 | 120.0 | 150.0 | 180.0 | |
| 0 | 1039 | 1042 | 1040 | 1041 | 1041 | 1038 | 1039 | |
| 5 | 1037 | 1041 | 1038 | 1034 | 1036 | 1035 | 1034 | |
| 15 | 1004 | 1007 | 998 | 1002 | 995 | 1002 | 997 | |
| 25 | 933 | 937 | 926 | 928 | 924 | 931 | 925 | |
| 35 | 835 | 843 | 829 | 829 | 819 | 828 | 826 | |
| 45 | 708 | 709 | 700 | 700 | 689 | 699 | 693 | |
| 55 | 560 | 561 | 545 | 555 | 543 | 554 | 546 | |
| 65 | 401 | 398 | 386 | 392 | 380 | 387 | 382 | |
| 75 | 229 | 235 | 222 | 226 | 211 | 225 | 217 | |
| 85 | 68 | 73 | 68 | 39 | 62 | 65 | 62 | |
| 90 | 3 | 5 | 5 | 4 | 2 | 1 | 1 | |

Total System Watts 29.9



LM-80 Qualified • LM-79 Certified Photometry

* LED manufacturers maintain a tolerance of ±7% on flux (lumens) and power (electrical) measurements. Kirlin photometrics are actual test data

▲ Cone of Light Key Dia. (in ft.) shown is where FC value is half the FC at nadir. Dist. Distance (Ft.) from fixture FC Footcandles at nadir (0°)
Dia. Circle of light at 50% of FC

3 Steps To "Artifact-Free" **Imaging**

- 1. Use complete Kirlin SmartLED™ MRI system: Luminaires, Remote Driver Cabinet, and RF Filters
- 2. Use a minimum #18 AWG twisted, shielded pair wire
- Use a 0-10V wall box dimmer that is approved for use with SmartLED™ MRI Lighting System (consult Owner's Manual); wall dimmers must be located outside of room shield and must NOT be filtered through SmartLED™ Filter